



B3DPS Coating Solutions Product Presentation

BASF 3D Printing Solutions (B3DPS) Status March 2023

BASF 3D Printing Solutions – Product Description









Ultracur3D[®] Coat F+ by Forward AM is a flexible waterborne 2k-basecoat designed to offer exceptional flexibility for elastic 3D Printing Materials and enables new possibilities for advanced applications – from functional prototyping through to end use serial production parts. Together with BASF Coatings GmbH we can offer outstanding technical support and an extensive range of colors to identify the ideal surface finish for your specific application.

Waterborne based coatings can be applied with a wide range of industrial spray guns, which allows **easy handling** and **reduces expensive hardware investments**.

In addition, a **customized color development** based on a physical sample, RAL or Pantone code is offered.






Substrate

BASF 3D Printing Solutions – Target Markets








BASF 3D Printing Solutions – Product Features







BASF 3D Printing Solutions GmbH

ams@basf-3dps.com

www.forward-am.com

BASF 3D Printing Solutions – Product Details



			0.000		0
	Norm	Specification	TPU01	PA 11	EL4000
Adhesion	ISO 2409	2mm blade distance	\checkmark	\checkmark	\checkmark
Rossflex	ASTM D1052	100.000 cycles	\checkmark	N / A	Ongoing
Martindale-Abrasion	ISO 12947-4	25.000 cycles	\checkmark	Ongoing	Ongoing
Color fastness – dry	ISO 105-X12	100 double strokes	\checkmark	\checkmark	\checkmark
Color fastness – wet	ISO 105-X12	100 double strokes	\checkmark	\checkmark	\checkmark
UV-Resistance	ISO 4892-2A	1000h	\checkmark	Not tested	Not tested
UV-Resistance	ISO 4892-2B	1000h – Cycle 3	\checkmark	\checkmark	\checkmark
Hydrolysis		70°C at 95% RT for 168h	\checkmark	\checkmark	\checkmark
Thermal storage		80°C for 240h	\checkmark	\checkmark	\checkmark
Burning behavior	FMVSS 302		< 100mm/min		
Cytotoxicity	ISO 10993-5	Tested on medical steel		\checkmark	
Skin sensitization	ISO 10993-10	Tested on medical steel		\checkmark	
Skin irritation	ISO 10993-10	Tested on medical steel		\checkmark	

BASF 3D Printing Solutions GmbH

ams@basf-3dps.com

www.forward-am.com

BASF 3D Printing Solutions – Product Support








ams@basf-3dps.com

BASF 3D Printing Solutions GmbH

BASF 3D Printing Solutions – Color Support







Ultracur3D Coat F+ Uni Colors



Ultracur3D Coat F+ Effect Colors

Metallic Silver

Metallic Blue

BASF 3D Printing Solutions – Color Support











Spray Application Process

				ရာ		ဂျီ	\$ \$\$
Surface Pretreatment	Mixing	Cleaning Isopropanol	1st Spraying	Flash-Off 5'23°C	2nd Spraying	Flash-Off 5'23°C	Drying 30'80°C
Mixing ratio:		100 : 4 by weight			Spray passes	1.5 - 2	2
Hardener:		Ultracur3D [®] Hardener F+			Layer thickness	s 25 ± 5	μm
Potlife at 20°C:		2h		ရျ	Flash of at 23°C	C 5min	
Shelf life (5 – 35°C)		6 months			Final drying	30mir	n at 80°C



Surface pretreatment Blasting for 30min at 3bar Remark: Blasting is recommended only for chemically smoothed surfaces.

BASF 3D Printing Solutions – Equipment Support





Protective clothing

1) Coating suit

2) Coating Mask + Filter



E.g.: 3M[™] 7500 Series Face Mask

- 3) Safety shoes
- 4) Single use gloves
- 5) Safety glasses



E.g.: HONEYWELL SVP200 ANTI-FOG

Coating equipment

1) Spray gun:



E.g.: SATAjet 5000 B

E.g.: Iwata WS 400 Evo

2) Spray booth

- Spray wall with filters
- Spray wall with air/water separation
- Closed spray cabin with air regulation



1) Drying oven:

- Minimal drying temperature: 80°C
- Air circulation



E.g.: XUE225 universal oven Essential



