

# Asiga - Pro 4K

## 3D Printing Workflow: Ultracur3D® RG 3280

Technology: DLP

### PRINT SETTINGS

Layer Thickness (µm)	Irradiance (mW/cm <sup>2</sup> )	Exposure Time (s)
50	4,6	0,999

	WASH CYCLE 1	WASH CYCLE 2
Agitation Method	Rotor / Propeller	Rotor / Propeller
Cleaner	IPA	IPA
Cleaning Time (min)	1	1



### WAIT BEFORE POST CURING

Waiting Time (min) None      Temperature (°C) None

### POST CURING

Model	Otoflash G171
Settings	N.A.
Atmosphere	Ambient
Time (min) or Flashes	3000
Flip & Repeat	Yes

### THERMAL TREATMENT

Ramp up (°C / min)	1
Holding Temp. (°C)	150
Holding Time (h)	3
Ramp down (°C / min)	1