



# Miicraft - 125 Y 385 nm

## 3D Printing Workflow: Ultracur3D® DM 2505

Technology: DLP

### PRINT SETTINGS

Layer Thickness (µm)	Irradiance (mW/cm2)	Exposure Time (s)
100	4	3,5

### WASH CYCLE 1

### WASH CYCLE 2

Agitation Method	Ultrasonic	Ultrasonic
Cleaner	Ultracur3D® Cleaner	IPA
Cleaning Time (min)	3	3



### WAIT BEFORE POST CURING

Waiting Time (min) 30      Temperature (°C) 40

### POST CURING

Model	Dymax ECE 2000
Settings	N.A.
Atmosphere	Ambient
Time (min) or Flashes	5
Flip & Repeat	Yes

### THERMAL TREATMENT

Ramp up (°C / min)	N.A.
Holding Temp. (°C)	N.A.
Holding Time (h)	N.A.
Ramp down (°C / min)	N.A.