

Stratasys - Origin One

3D Printing Workflow: Ultracur3D® RG 3280

Technology: DLP

PRINT SETTINGS

Layer Thickness (µm)	Irradiance (mW/cm ²)	Exposure Time (s)
100	5	1,4

	WASH CYCLE 1	WASH CYCLE 2
Agitation Method	Rotor / Propeller	Rotor / Propeller
Cleaner	IPA	IPA
Cleaning Time (min)	2	2



WAIT BEFORE POST CURING

Waiting Time (min) None Temperature (°C) None

POST CURING

Model	Onulis WRAP Cure
Settings	N.A.
Atmosphere	Ambient
Time (min) or Flashes	30
Flip & Repeat	No

THERMAL TREATMENT

Ramp up (°C / min)	N.A.
Holding Temp. (°C)	N.A.
Holding Time (h)	N.A.
Ramp down (°C / min)	N.A.